



## Model BO6050J Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	266901-4	TAPPING SCREW 4X14	1	PC.
002	456126-0	CHANGE KNOB	1	PC.
003	346914-2	CHANGE PLATE	1	
004	231490-8	COMPRESSION SPRING 5	1	PC.
005	346913-4	GUIDE PLATE	1	PC.
006	266034-5	TAPPING SCREW CT 4X16	4	PC.
007	456117-1	TOP COVER	1	PC.
008	211333-0	BALL BEARING 6804LLU	1	PC.
009	227386-9	SPUR GEAR 31	1	PC.
010	424748-4	BRAKE RING	1	PC.
011	261157-4	SPONGE WASHER 40	1	PC.
012	227387-7	INTERNAL GEAR 34	1	PC.
013	961004-6	RETAINING RING S-8	1	PC.
014	267290-0	FLAT WASHER 18	1	PC.
015	346912-6	PLATE	1	PC.
016	227648-5	SPIRAL BEVEL GEAR 43	1	PC.
017	213707-1	O RING 65	1	PC.
018	266060-4	TAPPING SCREW 4X65	1	PC.
019	183B68-4	HEAD COVER SET	1	PC.
	D10	INC. 22		
020	265995-6	TAPPING SCREW 4X18	4	PC.
021	456127-8	PAD PROTECTOR	1	PC.
022	183B68-4	HEAD COVER SET	1	PC.
	D10	INC. 19		
023	424747-6	RUBBER GUARD	1	PC.
024	266050-7	TAPPING SCREW 4X30	4	PC.
025	143324-2	GEAR HOUSING COMPLETE	1	PC.
026	961110-7	RETAINING RING S-30	1	PC.
027	211445-9	BALL BEARING 6906DDW	1	PC.
028	911119-9	PAN HEAD SCREW M4X12	3	PC.
029	143325-0	OUTER SPINDLE COMPLETE	1	PC.
030	143376-3	SHAFT LOCK COMPLETE	1	PC.
031	233285-5	COMPRESSION SPRING 4	1	PC.
032	211131-2	BALL BEARING 6001DDW	1	PC.
033	319330-1	BALANCER	1	
034	911119-9	PAN HEAD SCREW M4X12	3	PC.
035	143375-5	INNER SPINDLE COMPLETE	1	PC.
036	326582-7	COVER	1	PC.
037	253024-7	FLAT WASHER 10	1	PC.
038	216413-7	THRUST NEEDLE CAGE 1024	1	PC.
039	213445-5	O-RING 26	1	PC.
040	326581-9	FLANGE	1	PC.
041	961006-2	RETAINING RING S-10	1	PC.
042	197314-7	PAD 150 SET	1	PC.
043	143327-6	GEAR HOUSING COVER COMPLETE	1	PC.
044	213445-5	O-RING 26	1	PC.
045	961002-0	RETAINING RING S-6	1	PC.
046	227647-7	SPIRAL BEVEL GEAR 11	1	PC.
047	210059-1	BALL BEARING 6000DDW	1	PC.

048	253758-2	FLAT WASHER 10	1 PC.	
049	513441-6	ARMATURE ASS'Y 115V	1 PC.	
	D10	INC. 50-56		
050	240084-8	FAN 60	1 PC.	
051	681636-0	INSULATION WASHER	1 PC.	
052	210034-7	BALL BEARING 607LLB	1 PC.	
053	421868-5	LABYRINTH RUBBER RING 19	1 PC.	
054	267756-0	WAVE WASHER 6	1 PC.	
055	688117-5	MAGNET SLEEVE	1 PC.	
056	259039-2	SELF LOCK 6	1 PC.	
057	266049-2	TAPPING SCREW 4X75	2 PC.	
058	456116-3	BAFFLE PLATE	1 PC.	
059	621771-2	FIELD 115V	1	
060	851L09-5	BO6050 NAME PLATE	1	
061	419566-3	SWITCH KNOB	1 PC.	
062	456122-8	FRONT SWITCH LEVER	1 PC.	
063	456124-4	PICUP COIL COVER	1 PC.	
064	233071-4	COMPRESSION SPRING 4	1 PC.	
065	456123-6	REAR SWITCH LEVER	1 PC.	
066	651423-1	SWITCH	1 PC.	
067	265995-6	TAPPING SCREW 4X18	1 PC.	
068	687681-3	STRAIN RELIEF	1 PC.	
069	682559-5	CORD GUARD 8	1 PC.	
070	664064-4	POWER SUPPLY CORD AWG#18-2-2.5	1 PC.	
071	456120-2	MOTOR HOUSING	1 PC.	
072	807P04-7	INDICATION LABEL	1	
074	620464-8	CONTROLLER	1 PC.	
076	643770-4	BRUSH HOLDER	2	
077	266007-8	TAPPING SCREW BIND PT 3X10	2 PC.	
078	CB325	CARBON BRUSH SET CB-325 (195001-2)	1 SET	
079	654532-5	TERMINAL BLOCK 1P	1 PC.	
080	456121-0	REAR COVER	1 PC.	
081	265995-6	TAPPING SCREW 4X18	1 PC.	
082	143326-8	NOZZLE COMPLETE	1 PC.	
A01	143328-4	GRIP 36 COMPLETE	1	
A02	143676-1	CONNECTOR PLASTIC CASE (TYPE3)	1	
	C10	453974-8	LATCH	4 PC.
A03	838246-6	INNER TRAY	1	
A04	807T73-2	BO6050J INDICATION LABEL	1	
A05	807T74-0	BO6050J PLASTIC CASE LABEL	2	
A06	794610-0	ABRASIVE DISC 150#120	1 SET	
D01	652008-6	PAN HEAD SCREW M3.5X7	2 PC.	
D02	654037-5	INSULATED TERM. FT1.25-M3	2 PC.	
D05	654509-0	CONNECTOR 2-SD	1 PC.	